

Automated Cart3D Off-Body Pressure Analysis Results

Wu Li NASA Langley Research Center

First AIAA Sonic Boom Prediction Workshop January 11, 2014



- Cases analyzed, flow solver, and computing platform
 - $\circ~$ Cart3D inviscid solutions on Linux clusters using shared memory
 - $\circ~$ SEEB: Under-track pressure distributions at H = 21.2 and 42.0 inches
 - Delta Wing: All off-body pressure distributions for off-track angle phi = 0, 30, 60, and 90 deg at H = 0.0127, 0.53848, 0.62992, and 0.80772 m
- Automated Cart3D sonic boom analysis process
- Analysis results for SEEB body-of-revolution
- Analysis results for Delta Wing
- Conclusions

Automated Cart3D Off-Body Analysis Process



- User inputs: Mach, AoA, off-body location, Xverts (x-direction grid density), and surface triangulation.
- Trial-and-error process: Adjust Xverts until the volume mesh has the desirable density (20M+ cells for our standard under-track 3BL dp/p analysis).
- Verification: Use the largest Xverts that the computer will generate a volume mesh.







The yz-plane for SEEB geometry reflection

Cart3D Analysis of SEEB-080

- NASA
- Mach = 1.6, AoA = 0, mesh size is about 18M cells, global residual < 0.1, 600 iterations.</p>
- Two sets of analysis results for off-body dp/p (dx = 0.12): one set uses a grid perfectly aligned with Mach angle and another has a 2 deg off-set between grid line and Mach angle.



Cart3D Comparison of SEEB-080 and SEEB-200

- NASA
- Mach = 1.6, AoA = 0, mesh size is about 18M cells, global residual < 0.1, 600 iterations.</p>
- Two sets of analysis results for off-body dp/p (dx=0.12): one set uses SEEB-080 and another uses SEEB-200.



Cart3D Analysis of Delta Wing at Off-Track Locations

- NASA
- Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.
- For each off-track location, the configuration is rotated by the off-track angle along the yaxis to convert the off-track analysis into the under-track one (with a configuration nonsymmetric with respect to the xz-plane).







Cart3D Under-Track Analysis Results for Delta Wing

- Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.
- Global residual < 0.2, 1000 iterations.



Cart3D Under-Track Analysis Results for Delta Wing (II)

- Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.
- Global residual < 0.2, 1000 iterations.
- The average spacing between dp/p points = 0.003.



Comparison of Cart3D dp/p at H = 0.53848 for Delta Wing

Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.



Global residual < 0.2, 1000 iterations.

Comparison of Cart3D dp/p at H = 0.62992 for Delta Wing

Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.



• Global residual < 0.2, 1000 iterations.

Comparison of Cart3D dp/p at H = 0.80772 for Delta Wing

Mach = 1.7, AoA = 0, mesh size is about 26M for under-track and 54M cells for off-track.



Global residual < 0.2, 1000 iterations.



- The most time-consuming aspect of the automated Cart3D off-track dp/p analysis is to use a trial-and-error approach for generating a mesh of desirable quality by using one control parameter (x-direction mesh density).
- The current automated Cart3D analysis process for off-body dp/p is very robust and extremely easy to use for analysis of both in-house and external geometry models.
- Knowledge capturing and reduction of manual steps are very important in any engineering analysis process (including CFD analysis) at production level.